

HOT DOG 10L

FR

- Remplissez l'appareil avec de l'eau + saucisse et ne dépassez pas le niveau MINIMAL ou MAXIMAL.
 - Connectez l'appareil à la prise électrique approprié.
 - Démarrez l'appareil en appuyant sur le bouton vert ON/OFF.
- Réglez la température souhaitée en tournant le bouton de réglage de la température dans le sens horaire ou antihoraire (jusqu'à 85°C). Le voyant orange s'allume.
 - Après avoir atteint la température souhaitée, le voyant orange s'éteint automatiquement.

NL

- Vul het reservoir met water en worsten en zorg dat het waterpeil tussen het MIN- en MAX-niveau blijft.
 - Sluit de stekker aan op een geschikt stopcontact.
 - Schakel het apparaat in door op de groene AAN/ UIT-knop te drukken.
- Selecteer de temperatuur door de temperatuurknop (tot 85°C) met de klok mee te draaien. Daarna zal de oranje indicator oplichten.
 - Zodra de ingestelde temperatuur is bereikt, zal de oranje indicator automatisch stoppen met branden.

EN

- Fill the container with water & sausages only between the MIN and MAX level.
 - Connect the power plug with a suitable electrical outlet
 - Turn ON the appliance by pressing the green ON/ OFF switch.
- Select the temperature by turning the temperature control (up to 85°C) clockwise. Then, orange indicator lights up.
 - Once the set temperature is reached, the orange indicator will go off automatically.

FESTI
— R E N T —

02 / 640 41 40
rent@festi.be · www.festi.be