

FOUR HANNO GAZ

FR

- Brancher la bombonne adéquate et ouvrir le robinet.
- Tourner le bouton vers la gauche et le maintenir enfoncé.
- En même temps, enflammer la rampe de gaz avec un briquet ou un chalumeau. il est possible que le gaz mette un peu de temps à arriver depuis la bombonne jusqu'à la rampe.
- Garder le bouton enfoncé pendant 15 secondes, le temps que la sécurité chauffe.
- Lâcher la pression et tourner le bouton plus ou moins loin vers la droite en fonction de la puissance souhaitée.
- ! Pour terminer, fermer la bombonne de gaz.

NL

- Sluit de juiste gasfles aan en open de kraan.
- Draai de knop naar links en houd hem ingedrukt.
- Tegelijkertijd, steek je de gasbar aan met een aansteker. Het kan even duren voor het gas van dehouder naar de gasbar gaat.
- Houd de knop 15 seconden ingedrukt terwijl de veiligheid opwarmt.
- Laat de druk los en draai de knop meer of minder naar rechts, afhankelijk van het gewenste niveau.
- Tenslotte, sluit de gasfles.

EN

- Connect the correct gas cylinder and open the valve.
- Turn the button to the left and keep it pressed down.
- At the same time, ignite the gas bar with a lighter. It may take some time for the gas to reach the bar from the tank.
- Press and hold the button for 15 seconds while the safety is heating up.
- Release the pressure and turn the button more or less to the right, depending on the desired grade.
- Finally, close the gas bottle.