

Bouilloire

FR

- Assurez-vous que le robinet est fermé.
- Versez la boisson dans la bouilloire jusqu'au niveau "MAX" inscrit sur la paroi intérieure de la cuve.
 - Installez le couvercle et vissez-le jusqu'à ce qu'il se bloque.
 - Allumez l'appareil en mettant le commutateur en position "1".
- Ajustez la température souhaitée au moyen du bouton de thermostat. (Réglage maximum 100° C.).
 - Lorsque la boisson a atteint la température réglée, le voyant vert s'allume.
 - Ouvrez le robinet. La boisson coule de la bouilloire.

NL

- Zorg ervoor dat kraan dicht is.
- Vul de ketel met drank tot de "MAX" aanduiding aan de binnenzijde van de ketel.
 - Plaats de deksel en draai de deze tot deze blokkeert.
 - Schakel het apparaat in door de schakelaar in de "1" stand te zetten.
- Stel met de thermostaatknop de gewenste temperatuur in. (Instelbereik tot max 100 ° C.)
- Indien de drank de ingestelde temperatuur heeft bereikt, gaat het controlelampje groen branden.
 - Open de kraan. De drank loopt uit de ketel.

EN

- Make sure the tap is closed.
- Fill the appliance with wine up to the MAX level indicated on the inner wall of the reservoir.
 - Fasten the lid securely by turning it until it locks into place.
 - Switch the appliance on by setting the dial to position 1.
- Use the thermostat knob to select the desired temperature. (Maximum temp setting is 100°C)

- When the wine has reached the selected temperature, the green light will be illuminated.
 - Open the tap and drain the wine out of the urn.

